


MODEL 6347DWDE



Item	Part	Qty.		Item	Part	Qty.	
No.	No.	Used	•	No.	No.	Used	Description
2	266130-9	10	TAPPING SCREW BIND PT 3X16				
4	344391-2	2	BIT HOLDER				
5	183451-3	1	HOUSING SET (INCL. FIG. 20 & 21)				
6	417879-6	1	MODE CHANGE LEVER				
7	125102-2	1	SPEED CHANGE LEVER ASS'Y (INCL. 2				
			EA. 231433-0 COMPRESSION SPRING 4)				
8	232182-2	1	LEAF SPRING				
9	417880-1	1	F/R CHANGE LEVER				
10	638143-4	1	SWITCH UNIT (INCL. 643918-8 BATTERY				
			HOLDER, & 650528-4 SWITCH C3SA-MH				
			SINGLE W/O LOCK VARIABLE)				
12	251464-3	1	- FLAT HEAD SCREW M6X22				
14	125160-8	1	GEAR ASS'Y				
15	638138-7	1	YOKE UNIT				
16	619082-7	1	ARMATURE				
17	638139-5	1	ENDBELL COMPLETE				
18	191971-3	1	CARBON BRUSH CB-430 2PC./SET				
19	643954-4	2	BRUSH HOLDER CAP				
20	819064-1	1	MAKITA MARK				
21	183451-3	1	HOUSING SET (INCL. FIG. 5 & 20)				
22	231829-5	1	TENSION SPRING 2				
23	233353-4	1	COMPRESSION SPRING 2				
24	417966-1	1	LOCK LEVER				
ACCESSORIES							
13	763158-3	1	KEYLESS DRILL CHUCK 13				
A01	414938-7		BATTERY COVER				
	784614-0	1	+- BIT 2-45				
	824660-2	1	PLASTIC CARRYING CASE				
		-	(INCL. 1 EA. 417723-7 HANDLE,				
			& 2 EA. 417724-5 LATCH)				
A04	DC1803	1	BATTERY CHARGER				
A05	193159-1		18V BATTERY 1834				
		_					